



CONTENITORE CIBO
FOOD CONTAINER

SCHERMO
DISPLAY

CAMBIA UNITÀ DI MISURA
CHANGE UNIT OF MEASUREMENT:
g / ml / cup / oz

PULSANTE
BUTTON:
ON/OFF/RESET

BATTERIA
INCLUSA
BATTERY
INCLUDED



Material:	ABS
Size:	9 x 23 x 5 cm
Weight:	80 g

CIO076



8 014302 317904